

## NDZ P365 X-Macro Magwell Instructions

1. Push pin out from this side and slide back strap down.
2. Insert nut into slot in back strap and slide back strap back into place and replace pin.
3. Insert front of grip into the front of the magwell first, then push the back of the magwell up and over the back of the grip.
4. Insert screw and tighten until snug.  
**DO NOT OVER TIGHTEN**

