



Push the plug into the cavity for a friction fit. To remove, use a punch tool in the indicated area and pry up.