



NDZ promotes the use of safety practices and gear when working on any firearm

Install rear slide plate with indents for set screws with slide on the firearm. Slide SRP (slide racker plate) over the rear plate from the top down. Screw in the provided set screws (2) and tighten.

WARNING!

YOU MUST REMOVE SRP part BEFORE REMOVING SLIDE FOR FIELD STRIPPING! Failure to do so may result in scratching the FCU.